

6 YEAR PRODUCT WARRANTY

Congratulations on purchasing Australia's finest power protection.

Unless otherwise stipulated in a separate and specifically superseding Product Guarantee, all THOR power protection products are guaranteed for a period of six (6) years from date of original purchase against damage or failure due to faulty components or workmanship. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Notice to New Zealand Consumers

Our goods come with guarantees that cannot be excluded under the Consumer Guarantees Act 1993. This warranty should not be construed as any attempt to contract out of or exclude any of the guarantees available to any consumers under this Act provided that you agree that the provisions of the Consumer Guarantees Act 1993 will not apply if you are acquiring the goods for the purpose of a business.

This warranty shall not cover normal and expected wear and tear, damage, malfunction or failure resulting from accident, misuse or misapplication, improper or unauthorised repair, neglect, modification or use of unauthorised replacement parts or accessories, operation of the unit beyond its technical and environmental specifications, infestation by insects or vermin or interfacing supplied by the customer or improper voltage. The warranty shall be void if the rating label or date code has been removed or altered.

This THOR product is sold by the Dealer or Agent as principal. The Dealer or Agent has no authority from THOR Technologies Pty Ltd to express any additional warranty or guarantee on the Company's behalf except as herein contained. This warranty only applies to the purchase and use of the product in Australia and New Zealand.

To the extent permitted by the relevant legislation in Australia and New Zealand, THOR Technologies Pty Ltd will not accept or have any other responsibility or liability whatsoever for negligence or liability for incidental, consequential, indirect, or special damages, including without limitation, loss of actual or anticipated revenue or loss of data or for data being rendered inaccurate.

Thor Technologies Pty Ltd

1300 766 140

warranty@thortechnologies.com.au

Po Box 95, Karrinyup,
Western Australia,
Australia 6921

THOR TECHNOLOGIES COMMITMENT TO EXCELLENCE

PRODIGY 8

MODEL: P8

Specifically built for top shelf systems like home theatre, entertainment systems, computers, sewing machines and any equipment that is processor controlled and sensitive to power fluctuations. Prodigy 8 includes a non-sacrificial Patented Surge and Surge protection as well as featuring Thor's exclusive Dynamic Active Tracking Filter Technology that improves performance of connected devices

PLEASE REVIEW THE FOLLOWING OPERATING INSTRUCTIONS TO ENSURE YOU RECEIVE MAXIMUM BENEFIT FROM THIS STATE OF THE ART FILTER AND PROTECTION DEVICE.

This model has Patented Spike and Surge Protection for all 8 AC outlets. There are two filter Banks. Bank 1 and Bank 2 which include the Dynamic Active Tracking filter technology allowing you to isolate groups of equipment from each other, preventing disruptive and damaging inter-circuit interference. To get optimum performance from this power board, please follow these simple rules:

1. Plug the AC power cord from your Prodigy 8 into your wall outlet and observe the status of the two LED lights.
2. When lit, EARTH OK indicates your power source is grounded. As any incoming transient spikes are firstly diverted to Earth/Ground. If this LED does not illuminate it is likely you have a wiring anomaly in your outlet or building, requiring the assistance of a qualified electrician to properly earth the outlet or building. It is a condition of our warranty that the unit is only connected to a correctly wired environment.
3. The PROTECTION ON LED indicator should always be on when the unit is plugged into a wall outlet. Failure for this LED to operate and a continuous alarm sound indicates the circuitry has performed its function - preventing damaging spikes and surges from entering your equipment and the unit needs to be replaced.
4. Unfiltered Bank (1 Outlet) has Patented spike and surge protection with no filtration. Use the unfiltered outlet for devices that prefer no filtering of the incoming power.
5. Bank 1 (3 outlets) features our Dynamic Active Tracking filter technology, as well as the Patented Spike and Surge protection. Connect up to three devices that you deem sensitive equipment for clean filtered power delivery.
6. Bank 2 (4 outlets) features the same technology as Bank 1 but has additional earth loop/ hum noise reduction, making it ideal for your most sensitive equipment.

WHEN INSTALLING THE AV/TV ANTENNA PROTECTION FOR YOUR RECEPTION YOU MUST ENSURE THE AC MAINS POWER CORD IS PLUGGED INTO A CORRECTLY INSTALLED WALL SOCKET FIRST.

THE PRODUCT MUST BE CONNECTED TO A CORRECTLY INSTALLED 230-240V MAINS WALL SOCKET WITH A PROTECTIVE EARTH CONNECTION BEFORE CONNECTING OR DISCONNECTING THE DATA/COMMUNICATIONS CABLES. CONNECTIONS WHETHER SOCKET OUTLETS OR PRODUCTS MUST BE DONE BY QUALIFIED PERSONNEL AT ALL TIMES.

IF SUPPLY CORD IS DAMAGED, IT SHALL BE REPLACED BY THE MANUFACTURER, ITS SERVICE AGENT OR SIMILARLY QUALIFIED PERSON IN ORDER TO AVOID A HAZARD

This device has been designed for indoor use on AC mains which meet Australian and New Zealand AS/NZ standards.

1. Connect your incoming F Type connection from your wall outlet directly to the "IN" F Type connector on the end of the board.
2. Now connect "OUT" from Prodigy 8 F Type connector to your TV or recording/streaming device
3. Now all incoming signals must pass through the protected outlets on your Prodigy 8, providing you with maximum protection and reliability your products deserve.
4. The 2 pairs of "F" type connectors will allow connection to Pay TV decoders that require 2 incoming F Type connections.
5. Connect the incoming communication RJ45/network using the same principle as the instructions from 1 to 3 above.

Note: There is a warning alarm/buzzer that may momentarily activate if a spike or surge is detected. There is no need to be concerned as the Prodigy 8 is just letting you know it is doing its job. If a continuous audible alarm sounds then the protection has been damaged or exhausted. If this happens then the board has done its job protecting your devices and will require replacement.

Should you feel your THOR power board is malfunctioning, unplug the unit from the wall and contact our info-line 1300 766 140 during business hours (after hours please leave your details on the THOR info-line and we will return your call the following working day).

Please have available at the time you speak with our service department the unit so you may identify the model number and the date of manufacture which is impressed on the back of the unit as well as a description of the difficulty you are experiencing and your retail invoice or bill of sale. Alternatively you can contact us through our website www.thortechnologies.com.au and select Support, then Warranty to complete necessary fields.

